



How To Fold An F-117 Stealth Fighter




STEP 1

Start with an 8.5" x 11" piece of paper. Lay it flat on a table and then fold the paper exactly in half along its long edge. Make sure all folds are sharp, crisp, and precise.




STEP 2

1. Make a crease for the **tail** by folding about a 2" wide flap from the new edge of the page (up to nearly half the page length — see above). 2. Open it back flat.




STEP 3

Unfold the paper and lay it flat on the table. The creases for the **tail** should be at the bottom. Fold the upper right and left corners of the page down along the center line of the paper. They should be even.




STEP 4

Fold the top, or **nose**, of the page down about 1/8" below the new folds from **STEP 3** — see above. When folding, make sure the tip of the **nose** stays centered on the center line of the page.




STEP 5

Now fold the new right and left corners down along the center line in the same way as in **STEP 3**.




STEP 6

1. Fold the small exposed triangle flap up so the point at its tip meets the center line crease. This will help hold the body together. 2. Flip the plane over so the folded flaps are underneath and the **nose** is pointing up.




STEP 7

This step is tricky. While pushing the top **tail** section up and the bottom down, fold the plane in half along the center line. When folded correctly, the **tail** section will be hidden between the **wing flaps**.



STEP 8

Rotate the plane so it appears as above. Fold each **wing** down so their outer edges are even with the bottom edge of the plane. The tail should be the only remaining flap sticking up from the middle.




STEP 9

You can now open up the wing flaps and adjust them so they are even. Angle them down slightly for more stability. You are now ready to take a test flight with your new **F-117 Stealth Fighter**.


TIPS

Here are some hints for making your **F-117 Stealth Fighter** really soar:

1. Throw the plane with a level or slightly nose-up push throw.
2. Try placing a small paper clip on the bottom nose of the plane for greater distance.
3. Cut the top tail of the plane down the center and bend each tail flap slightly outward to form two stabilizers.




How To Fold A Classic Paper Airplane




STEP 1

Start with an 8.5" x 11" piece of paper. Lay it flat on a table and then fold the paper exactly in half along its long edge. Make sure all folds are sharp, crisp, and precise.




STEP 2

Fold the short edge of one side down to the first fold (producing a 45° angle). Repeat for the other side.




STEP 3

Fold down the new fold you have created to the original fold you did in [Step 1](#). Repeat for the other side.



STEP 4

Repeat [Step 3](#) for both sides.



STEP 5

Hold Centre and open wings out.
Now Throw!!!